

Clock Configuration (Forensic Models Only)

To configure the internal clock module, while in Flash Drive Mode, open the file named TIME_OLD.TXT. Update the file using the following format and then *Save As*: TIME.TXT

It will look like: \$DateTime=10-05-12/12:14PM #Format: MM-DD-YY/HH:MMxM

MM=10
DD=05
YY=12
HH=12
MM=14
AM/PM=PM

Values must match the options below:

- YY sets the clock year value. (00 to 99)
- MM sets the clock month value. (01 to 12)
- DD sets the clock day value. (01 to 31)
- HH sets the clock hour value. (01 to 12) or (00 to 23)
- MM sets the clock minute value. (00 to 59)
- AM/PM Sets the time format. (AM or PM) If AM is chosen, the specified hour is treated as before noon.

Note: The time and date will be updated when the keylogger is reconnected. For precise time setting, it is a good idea to set the time a few minutes in advance, and restart the keylogger at the specified time.